

# Filtering Half Mask

**[ Product Name ]**

Filtering Half Mask

**[ Application and Limitation ]**

This product can be used to protect against the particulate generated during grinding, sand paper polishing, cleaning, sawing, bagging etc., or during the processing of ore, coal, iron ore, flour, metal, wood, pollen and certain other substances, liquid or non-oil based particles from sprays that do not emit oil aerosols or vapours.

This product can not be used to protect against harmful gas and steam, oily aerosol, asbestos, arsenic, cadmium, lead, 4,4'-diaminodiphenylmethane(MDA) or sandblasting.

**[ Executive Standard ]**

This product complies with European standard EN149:2001+A1:2009 FFP2 NR.

**[ Inspection Method ]**

Before use, check whether the packaging of the mask is damaged and the components are normal; if there are stains or damage, please stop using. Before entering the working area, must check the tightness between the mask and face, if there is leakage, please re-wear; if there is no leakage, you can enter the work area to work. (When feel a significant increase in breathing resistance, Or the mask does not meet the required standard, It is recommended to replace the product.)

**[ Instruction for Use ]**

1. Prior to wearing the face mask, inspect the face mask for damage and contamination. Verify all components of the mask such as ear loops, nose clip, etc. are in good condition.
2. Stretch and unfold the mask, place a earloop around each ear.
3. Completely cover the mouth, nose and lower jaw, press the nose clip tightly.
4. Stretch the ear loops appropriately to adjust the tightness, making the mask and the face fit properly.
5. Exhale sharply after completely cover the face, if air blows on your face or eyes, readjust the mask to ensure the seal.

**[ Storage Conditions ]**

Packed masks should be stored in a room free of corrosive gases and well-ventilated (temperature: (-20~50)°C; humidity: <85%).

**[ Transportation requirements ]**

The transportation process should be carried out according to the contract. It should be prevented from deformation under heavy pressure, direct sunlight, scratching of hard objects, and rain or snow or liquid materials.

**[ Warning ]**

1. Do not use if package has been previously opened or damaged.
2. The product should be used as soon as possible after open the package; Do not use the expired product.
3. Single Use Only. Please do not reuse or exchange to use with other's; The recommended use time is 4 hours.
4. If you feel dizzy, lightheaded, or nauseated, remove the mask, and get the medical attention.
5. Discard the mask if it becomes more difficult to breathe through it.
6. Dispose of used product in accordance with applicable regulations.
7. Store in well-ventilated, dry place. Prevent heavy pressure, direct sunlight, hard objects.

**[ Symbol ]**

Manufacturer: Hangzhou Shanyou Medical Equipment Co., Ltd  
Add: No. 138, Louta Development Zone, Guancun Village, Louta Town, Xiaoshan District, Hangzhou, 311266, Zhejiang, China  
Tel: 0086-571-82222888

Distributor: SCSGo GmbH  
ADD.: No. 10 Westring, 67269 Grünstadt, Germany

See information supplied by the manufacturer.  
This product is a non-medical device.